

# **ROSTA** Anti-vibration Mounts

Shock and Vibration absorbing Machine Mounts high degree of isolation — tearproof — absorption of solid-borne noise




# **ROSTA** Anti-

# highly elastical and fully tearproof vibration





# vibration Mounts dampers based on torsional rubber pivots





# **Selection table for Anti-vibration Mounts**

Туре	Description	Details	Illustration
ESL	<ul> <li>Anti-vibration Mounts for the absorption of tensile, pressure and shear load. Also ideal for wall and ceiling installations.</li> <li>8 load sizes from 200 N to 19'000 N per mount.</li> <li>Natural frequency between 3,5 – 8 Hz. Mounts are mainly used for overcritical machine installations (machine frequency &gt; mount frequency).</li> </ul>	Page 3.8 – 3.9	120
V	Anti-vibration Mounts for the absorption of tensile, pressure and shear load. Also ideal for wall and ceiling installations. 6 load sizes from 300 N to 12'000 N per mount. Natural frequency between 10 – 30 Hz. Mounts can be used for subcritical machine installations (machine frequency < mount frequency).	Page 3.10 – 3.11	
N	Mounting Feets consisting of insulating plate, glued-on top cover with built-in levelling jackscrew with spherical joint for compensation of up to 5° of floor unevenness. Insulating plate oil- and acid-proof.  3 load sizes from 1'500 N to 20'000 N per mount.  Natural frequency between 19 – 25 Hz.	Page 3.12	
NOX	Mounting Feets consisting of insulating plate, stainless steel glued-on top cover with built-in stainless levelling jackscrew with spherical joint for compensation of up to 5° of floor unevenness. Insulating plate oil- and acid-proof.  2 load sizes from 5'000 N to 20'000 N per mount.  Natural frequency between 19 – 22 Hz.	Page 3.12	1
Base plate P	Accessories: For all N and NOX mounting feet light metal cast base plates are available for the compensation of possible shear loads and/or for the positioning of the installation on the floor.	Page 3.12	
ISOCOL	Adhesive cushioning plates, self-adhesive plates for the installation of smaller machines/equipments. Plates oil- and acid-proof. (Adhesive power can be increased by moistening the plate with nitro thinner.)	Page 3.13	
ISOCOL U	Adhesive cushioning plates, self-adhesive plates with glued-on cast cover. With central hollow in cover for the positioning of the levelling jackscrew – also with lateral stop bar for machine positioning.	Page 3.13	Control of the contro

Further information to customized elements and installation examples as from page 3.14.




# **Technology Anti-vibration Mounts**

Manufacturers and suppliers of anti-vibration mounts usually offer different types of machine mount with varying natural frequencies to meet the required **detuning** between the excitation frequency of the machine and the natural frequency of the anti-vibration mount.

# 1. Isolation of Oscillations and Shocks

The vibration technology basically differentiates between two principal types of oscillation appearances (fig. 1). Sinusoidal oscillations of working equipments are usually amortised in an **overcritical** installation manner, shocks and impacts in a **subcritical** mounting manner.



### Frequency Proportion $\lambda$ (fig. (2))

#### $\lambda > \sqrt{2}$ : Overcritical


efficient vibration isolation, clearly definable effectiveness, also efficient solid-borne noise absorption

#### $\lambda = 1$ : Resonance field

uncontrolled swing-up, in the long term destructive for machine and mounts


#### $\lambda < 1$ : Subcritical

vibration isolation not definable, isolation results have to be measured out (before and after mount installation).




### Overcritical installations ( $\lambda > \sqrt{2}$ )

On overcritical installations the natural frequency of the mounts should show at least a detuning factor of 1:1,414 in regard to the excitation frequency of the machine. Usually, very efficient anti-vibration mounts feature a deep deflection capability offering a low natural frequency. Most of the generators, compressors, blowers and chargers are, therefore, in **overcritical** manner installed on relatively "soft" mounts. The resulting **detuning proportion** provides information about the expected **isolation-effectiveness** in % of the machine suspension. The adjacent chart (fig. 3) and the calculation formula (fig. 4) inform about the resulting vibration isolation in %.







### **Vibration** isolation

$$W = 100 - \frac{100}{\left(\frac{n_s}{60 \cdot fe}\right)^2 - 1} [\%]$$

n<sub>s</sub> = Revolution exciter (machine) [rpm]

fe = Natural frequency damper [Hz]

### Resonance field ( $\lambda = 1$ )

At equal values of the excitation frequency and the mount natural frequency an uncontrollable swing-up of machine and damper occurs. In the long run, this appearance will be destructive for machine and mount (fig. 2).

### Subcritical installations ( $\lambda < 1$ )

On subcritical installations (fig. 2) an anti-vibration mount with high mechanical stiffness and only small deflection behaviours should be chosen, e. g. ROSTA V mounts (high machine stability on mounts). In spite of the fact that the degree of isolation is not definable, this suspension efficiently absorbs **shocks** and **impacts** generated by relatively slow turning machines like e. g. mixers, crushers (cone-crushers), punching presses, sheet iron shears, etc. On **subcritical** installations the degree of isolation is not definable. Isolation results have to be measured out (before and after mount installation).

# 2. Solid-borne Noise Isolation


Whereas the isolation of mechanically generated oscillations and shocks are determined and dissipated by means of the aforementioned vibration dampening theory, the **solid-borne noise isolation** is subject to the technology of wave mechanics. The dampening effect is related to the proportion of the relevant acoustic resistance (acoustic resistance or wave resistance = acoustic velocity x material density). The adjacent chart (fig. 5) shows some comparative values of the resulting isolation proportions. Generally, using a rubber-steel composite mount, an ideal isolation result of the solid-borne noise can be expected – through the entire frequency range.






## 3. Active and Passive Isolation

Active or direct isolation (fig. (a)) means the direct absorption of oscillations, vibrations and shocks of a running machine by anti-vibration mounts, i. e. to prevent directly the transfer of the numerous machine vibrations into the substructure, basis frame and entire building. For the anti-vibration mount selection the knowledge of the interfering frequency (disturbance frequency), the stiffness of the machine structure and its gravity center as well as of the specific machine location in the building is required. Active isolations are usually overcritical machine installations on anti-vibration mounts (e. g. on ROSTA ESL mounts).



Passive or protective isolation (fig. 7) means to install a protective barrier between all kind of existing vibrations and shocks occurring in a factory or workshop towards sensitive installations like e. g. weighing and measuring instruments, laboratory equipment or electronic control units. The vibration technological situations usually vary in each case and are related to environmental situations, too. Often shocks and impacts come from outside, e. g. from motorways, railways, building sites or tooling machines, like punching presses, etc. Generally, the sensitive equipments shall be protected by installing them on rather "soft" anti-vibration mounts, e. g. ROSTA ESL or AB-D mounts absorbing most of these environmental impacts. It is frequently recommendable to consult also an engineering company having the tools and instruments to analyse the specific vibration appearances.



**Protective suspension mounts** for e.g. tooling machines are usually rather "hard" and show only little deflection under load. Too soft tooling machine mounts could actuate bending of the machine base what would influence negatively the precision of the work piece machining. Therefore, mounting feet for tooling machines are often consisting of hard rubber cushions deflecting only a few millimetres under load, but "shield" all combined vibration and shock appearances from the sensitive precision machine. Transmitted shocks and vibrations could affect the clean surface finishing of the work piece. Of course, in the interest of the fully horizontal positioning of the tooling machines, these anti-vibration mounts have to dispose of a levelling jackscrew with spherical joint for the compensation of the possible floor unevenness (e. g. ROSTA N or NOX mounts).









# **Mounting Feets**

# Type N Type NOX



# Accessory: Base plate P



# N and NOX

Art. No.	Туре	Load Gmin. – Gmax. [N]	Natural frequency Gmin. – Gmax. [Hz]	øΑ	С	D	L	SW	Weight [kg]	Material structure (rubber pad NBR with 50 ShA)	
05 058 001	N 80 M12	1'500 - 6'000	25 - 22	80	55	M12	100	10	0.3	zinced, cover blue painted	
05 058 002	N 80 M16	F1000 121000	5'000 - 12'000	22 - 19	80	136	M16	182	13	0.5	zinced, cover blue painted
05 058 102	NOX 80 M16	3000 - 12000	22 - 19	00	130	MIO	102	13	0.5	stainless steel 1.4301 and 1.4305	
05 058 004	N 120 M20	10'000 - 20'000	0'000 - 20'000 22 - 19	120 1:	139	39 M20	195	16	1.0	zinced, cover blue painted	
05 058 103	NOX 120 M20	10 000 - 20 000	22 - 19	120	139	MZU	173	10	1.0	stainless steel 1.4301 and 1.4305	

# Base plate P

Art. No.	Туре	Accessory to	øE	F	G	Н	ı	øK	L	Weight [kg]	Material structure	
05 060 101	P 80	N / NOX 80	80	92	110	140	4	12	5	0.1	11. 11. 1	
05 060 102	P 120	N / NOX 120	120	135	170	210	5	16	7	0.3	Light metal cast	

# Options by high volume supplies

- other thread sizes and lengths
- higher load capacities
- other painting
- imprint of company logo

# **Applications**

For the isolation of vibrations and solid-borne noise, also for machinery and apparatus requiring levelling, such as air conditioning plants, woodworking machinery, pumps, tanks, containers, transport systems, tooling machines, assembly lines and workshop equipment.

For further information to customized elements and installation examples as from page 3.14.





# **Applications!**

# A few examples:







ROSTA AG CH-5502 Hunzenschwi Phone +41 62 889 04 00 Fax +41 62 889 04 99 E-Mail info@rosta.ch Internet www.rosta.com

# **Administrative and Technical Information**

### 1. Guidance, services and offers

Please contact your local ROSTA representative listed in our representatives list on the back of the catalogue if you have any questions or concerns.

We require a full list of technical specifications including any available sketches and data sheets for the preparation of an appropriate offer. This information makes it possible for us to determine whether a standard or custom element is the most cost-effective solution for you. For complex applications, our representative or the home office will send you a questionnaire about the exact specifications for what you need.

Terms and conditions for payments and deliveries are included with our offer or available on our website at www.rosta.com → Company → General Terms

#### 2. Orders and deliveries

Please include the offer number on your order along with the exact quantity, product name and number. Please send your order to your local ROSTA representative.

### 3. Availability

Most of the standard products listed in our catalogue are available from stock through your local representative or directly from ROSTA AG.

Custom pieces for a specific customer requirement are produced and delivered as specified in your order confirmation. The delivery time for special custom pieces can be reduced by signing a call order agreement (make-and-hold-order) with ROSTA AG. Please contact us if you would like to discuss this.

#### 4. Technical information

Please observe the capacity limits for our elements as specified in the catalogue. If you are in doubt, please contact us or your ROSTA representative.

Please follow the assembly instructions detailed in the catalogue. Make sure that your assembly workers are instructed correctly. If you have any questions, please contact us or your ROSTA representative.

Assembling elements: To attach our elements or mounts, please always use the largest dimensioned standard machine bolts possible with a minimum strength class of 8.8 that fit into the drilled holes in the elements or attachment clamps. Use an ISO 898 table or your screw supplier's guidelines for the maximum tightening torque.

If in doubt, control your bolt attachments using the VDI Guidelines 2230.

Use DIN 125A stamped washers to attach housings with unworked drilled holes in the casting (for example AB 50) or oblong holes (for example MB supports).

### 5. Proviso

This catalogue and our other technical information are intended solely for your orientation and information; they may not be construed as absolutely binding in any way. We ask that you adapt the assembly and use of our products in a way suited to the prevailing conditions and situation.

The reproduction of this document in full or in part may only be done with our expressed written permission.





### **SUBSIDIARIES**

Australia www.rostaaustralia.com.au Canada www.rosta.ca China www.rostachina.com Germany www.rosta.de Italy www.rostaitalia.com USA www.rosta.com

#### **DISTRIBUTORS**

Argentina heuchert@ciudad.com.ar Austria www.haberkorn.com Belgium/Luxemburg www.atbautomation.eu Brazil www.atibrasil.com.br Chile www.riosan.cl Czechia www.rupet.eu Denmark www.jens-s.dk Finland www.sks.fi France www.rosta.com Great Britain www.kobo.co.uk Greece www.alexandris.com Iceland www.falkinn.is India www.technotalent.in Japan www.mikipulley.co.jp Lithuania/Latvia www.techvitas.lt Malaysia www.masterjaya.com.my Netherlands www.atbautomation.eu New Zealand www.saecowilson.co.nz Norway www.jens-s.no Peru www.grupo-isc.com Philippines www.severosyling.com Poland www.archimedes.pl Portugal www.april.pt Russia www.fam-drive.ru Singapore henry@smcomponent.com Slovenia www.m-trade.si South Africa www.orangevmc.co.za South Korea www.sewonworld.co.kr Spain www.tracsa.com Sweden www.kontima.se Thailand www.virtus.co.th Turkey www.entatek.com

#### **ROSTA AG**

Hauptstrasse 58 CH-5502 Hunzenschwil



Phone +41-62-889 04 00 Fax +41-62-889 04 99 E-Mail info@rosta.ch Internet www.rosta.com





